

SmartOne Solar Installation Guide

Steps to Installation

- 1 Locate the place on the asset in which you want to attach the **SmartOne Solar™**. The solar panel should always face outward.
- 2 Clean the surface area.
- 3 Dry the surface area.
- 4 Find and mark the rib location on the top of the trailer to ensure good connection.
- 5 Remove the tape from the back of the bracket.
- 6 If ambient temperature is cold, warm the surface area and tape.
- 7 Press the bracket firmly down on the asset.
- 8 Turn the unit "On". It must be in plain view of the SKY when being turned "On".
- 9 Alternatively: Drill 2 screws or apply 2 rivets to secure the bracket to the asset.
- 10 Apply a bead of silicone around the bracket. This is for extra wind shear protection.
- 11 Place the unit with the battery compartment facing the sky in the bracket.
- 12 Gently squeeze down on the unit till the silicone is compressed.
- 13 Screw in the 4 Philips screws to connect the unit to the bracket. Hand tighten.
- 14 Wipe any excess silicone off the sides of the unit.
- 15 The install is now complete!

